

# **UTILITY PANEL** by Master Mark Plastics

## **Instructions**

1. Predrill holes
2. Use a fastener that is smaller than the hole to allow for expansion/contraction depending on temperature.
3. Use a fastener with a pan head or add a washer.
4. Do not over tighten the fastener, snug is good.
5. If using an "H" channel, slide the sheets into the "H" channel and leave a gap for expansion/contraction.

*Silicone caulk can be applied into the "H" channel prior to installation for wet applications.*

*"H" channels are available at your local building materials center.*